



Insert the bronze washer before setting screw.

Table 145 : LNM Series Dimensions Table

Model No.	Major Dimensions (mm)						
	M	D	d	W	W <sub>0</sub>	K	m
<b>LNM 6×0.5</b>	M 6×0.5	14	10	6	3.3	12	M3
<b>LNM 6×0.75</b>	M 6×0.75	14.5	10	5	2.7	12	M3
<b>LNM 8×0.75</b>	M 8×0.75	16	11	6	3.3	13	M3
<b>LNM 8×1</b>	M 8×1	17	13	6.5	4	14	M3
<b>LNM10×0.75</b>	M10×0.75	20	16	7	4	17	M4
<b>LNM10×1</b>	M10×1	20	16	8	5	17	M4
<b>LNM12×1</b>	M12×1	22	17	8	5	19	M4
<b>LNM15×1</b>	M15×1	25	21	10	6	22	M4
<b>LNM20×1</b>	M20×1	35	26	13	8	30	M4
<b>LNM25×1.5</b>	M25×1.5	42	34	16	10	36	M6